


(+) 12 or 24 VDC input
Use 14ga wire
12vdc= 15 or 20
amp fuse
24vdc= 10 amp
fuse



(-) DC ground
Use 14 ga wire

Input Voltage must
match the voltage
rating of the
actuators being
used



SECONDARY STATION



PRIMARY STATION



NO CONNECTION
FOR REMOTE STATION



Ignition
Or Aux Switch
Primary Station
Only

- YELLOW 7
- GREEN 8
- BROWN 9
- WHITE 10

WHITE 3

BLACK 5

PORT ACTUATOR

WHITE 4

BLACK 6

STBD ACTUATOR

