


Stainless Steel Trim Tab Kits (Control Switch Not Included)

Lectrotab Kit without Control Switch	Kit Contains these Parts
XKA9X9	<p>2 – Actuators with 23' (7m) cable</p> <p>2 – Flat Stainless Steel Tabs, 12 Gauge</p> 
XKA9X12	
XKA9X18	
XKA9X24	
XKA9X30	
XKA9X36	
XKA12X9	
XKA12X12	
XKA12X18	
XKA12X24	
XKA12X30	
XKA12X36	
XKA12X42	

Stainless Steel Trim Tab Kit Model Number

<u>XK</u>	<u>A</u>	<u> </u>	<u>12</u>	<u>X</u>	<u>12</u>
XK = 23' (7m) Actuator Cable K = 6' (1.8m) Actuator Cable		No Designation = Control Not Included	1st Number = Tab Chord Length (inches)		2nd Number = Tab Width Across Transom (inches)
<p>A = Standard Actuator 12vdc, 2.25" (57mm) stroke, 8 second stroke time</p> <p>B = Standard Actuator 24vdc, 2.25" (57mm) stroke, 8 second stroke time</p> <p>S = Short Actuator 12vdc, 1.50" (38mm) stroke, 6 second stroke time</p> <p>C & D = See Note Below</p>					

Note:

Actuators are also available with a 4 second stroke time. 4 second stroke time model numbers begin with the letter "C" for 12vdc and "D" for 24vdc.

Please note that Lectrotab recommends using the 8 second stroke time for a smoother, more controlled boat response to tab adjustments.